



INTRODUCTION OF CERAMIC COATING



Bringing kitchens to life



CONTENTS

- 1 Cookware Products in the Market
- 2 Property Comparison of Coated Cookware Products
- 3 Ceramic Coating Manufacturers
- 4 Maleficence issues of PTFE and PFOA
- 5 Advantages of Ceramic Coating
- 6 Functional Ceramic Coating with Additives
- 7 Test Method of Non-Stick Property
- 8 Technological Limitation of Ceramic Coating in Non-Stick Property
- 9 Non-stick Improvement of NEOFLAM Ceramic Coating
- 10 Why NEOFLAM ?



INTRODUCTION OF
CERAMIC COATING

1

Cookware Products in the Market



NONCOATED COOKWARE

PORCELAIN

GLASS

STAINLESS STEEL

NIKEL SILVER



INTRODUCTION OF
CERAMIC COATING



Cookware Products in the Market



COATED COOKWARE

PTFE COATING

CERAMIC COATING

ENAMEL COATING

Property Comparison of Coated Cookware Products



INTRODUCTION OF CERAMIC COATING

PROPERTIES

	Ceramic Coating	PTFE coating	Enamel Coating
Non-stick	Good	Very Good	None
Pencil Hardness	9H ↑	4H ↓	9H ↑
Abrasion Resistance	Very Strong	Weak	Very Strong
Coating Heat Resistance	> 450°C	< 250°C	> 450°C
Non-Stick Heat Resistance	350°C	250°C	None
Chemical Resistance	Strong	Normal	Very Strong
Scratch Resistance	Strong	Poor	Very Strong
Heat Capacity	High	Low	High
F-IR Emission (Black Body, 100%)	88% ~ 90%	None	88% ~ 90%

Comparison of Coated Cookware Products



INTRODUCTION OF CERAMIC COATING

SAFETY

	Ceramic Coating	PTFE coating	Enamel Coating
Flammability	NO	YES	NO
Combustibility	NO	YES	NO
PAH (polycyclic aromatic hydrocarbon)	PASS	PASS	PASS
FDA, LFGB	PASS	PASS	PASS
RoHS	PASS	PASS	PASS
PFOS	NO	YES	NO
PTFE	NO	YES	NO

Comparison of Coated Cookware Products



INTRODUCTION OF CERAMIC COATING


PRODUCTION, ENVIRONMENT

	Ceramic Coating	PTFE coating	Enamel Coating
CO ₂ emission	Low	High	Very High
Curing Temp	180 ~ 230°C	250 ~ 450°C	800°C ↑
Multi-layers	1 ~ 2 layer (wet-on-wet)	2 ~ 3 layers, cured twice	2 ~ 3 layers
Spray method	Air pressure	Air pressure	-
Pre-heating	Yes	No	No
Cleaning agent	Water or Alcohol	Solvent	Water
Environment	Clean & no unpleasant smell	Contaminated & hazardous	Clean & no unpleasant smell

Comparison of Coated Cookware Products



INTRODUCTION OF CERAMIC COATING




Bringing kitchens to life



3

Ceramic Coating Manufacturers

CERAMIC COATING MANUFACTURERS







4

Maleficence Issue of PTFE and PFOA

① Treaty of Madrid

Scientists in the world make a public statement in Madrid about the Maleficence of PTFE and PFOA and urge government, manufacturers and consumers to forbid using perfluorinated compounds.

“ For these, we call on the international community to cooperate in limiting the production and use of PFASs and in developing safer nonfluorinated alternatives. We therefore urge scientists, governments, chemical and product manufacturers, purchasing organizations, retailers , and consumers to take the following action “





INTRODUCTION OF CERAMIC COATING

4

Maleficence Issue of PTFE and PFOA

EPA US Environmental Protection Agency

Español | 中文: 繁體版 | 中文: 简体版 | Tiếng Việt | 한국어

Learn the Issues | Science & Technology | Laws & Regulations | About EPA

Search EPA.gov

News Releases Contact Us Share

You are here: EPA Home » News Releases » EPAs Actions to Restrict PFOA and Similar Chemicals Yield Significant Human Health and Environmental Benefits

News Releases from Headquarters » Chemical Safety and Pollution Prevention (OCSPP)

EPAs Actions to Restrict PFOA and Similar Chemicals Yield Significant Human Health and Environmental Benefits

01/15/2015

WASHINGTON – To further agency and industry achievements, the U.S. Environmental Protection Agency (EPA) today proposed measures to ensure that perfluorinated chemicals that have been phased out do not re-enter the marketplace without review.

Ref: <https://www.epa.gov/newsreleases/epas-actions-restrict-pfoa-and-similar-chemicals-yield-significant-human-health-and>

Danger of nonstick cookingware

Toxic chemical PFOA perfluorooctanoate released at high temperatures

PFOA is linked in animal studies to:

Risks of liver, pancreatic, testicular and mammary gland tumors

Altered thyroid hormone regulation

Damage to your immune system

Reproductive problems, infertility and birth defects



- USA EPA announced in public what Teflon can cause cancer (Jun. 2005)
- Dupont company get agreement with 16million dollar penalty (Highest penalty in EPA history)
- **EPA request Dupont to decrease PFOA amount to 95% within 2010 and eject totally by 2015.**



Bringing kitchens to life




5

Advantages of Ceramic Coating

ENVIRONMENT

. Environmental Friendly Coating from Natural Mineral

Natural Raw Materials




Fewer VOC Release



Safe in Disuse



Health in Use



No PFOA & PFOS



No Heavy Metal

From the nature to the nature



Bringing kitchens to life



5

Advantages of Ceramic Coating

-FAR INFRARED RADIATION



- F-IR was found by William Herschel in 18th century
- F-IR is classified as near, mid and far infrared radiation
- The wave length of F-IR is very broad (0.75 ~ 1000 μm), and it is called as a heat radiation.
- I-IR is sorted as a electro-magnetic radiation
- 8~15 μm wave length F-IR is very good for human body.

· Human body release 9.6 μm wave length F-IR and it make resonance absorption when absorb 8~15 μm radiation.

· 8 -15 μm F-IR radiation make resonance with human body cell tissue and absorbed by soft body cell. This kind of absorption means increment of energy of molecules.

The molecull vibration in the body cell tissue activate body cell and generate energy in the body.






5


Advantages of Ceramic Coating

- F-IR EFFECT ON COOKWARE


. Heat Transfer mechanism of Ceramic Coating Cookware




Conduction



Convection



Radiation



Ceramic Coating



PTFE Coating




5

Advantages of Ceramic Coating

Process – low CO₂ Emission

Simple Manufacturing Process

[PTFE coating process, Two/Three layer]



[Ceramic coating process, One/Two layer]




1. Simple process compare with PTFE coating
2. Ceramics coating system can save lots of cost through wet on wet coating system and low temperature curing system.


- NEGATIVE ION (Needs to add Negative ion powder)

. Theoretical the ion which has negative charge called as a negative ion, but the negative ion that is good for health means "OH-" ion

. Because of porous structure of ceramic coating, it has much higher negative ion emission rate than any other coating material.



Crystal Structure of
Negative Ion Stone



Principle of Negative Ion
Emission

※ Principle of Negative Ion Generation

- Electric stone has fixed pole and move electrons from positive pole to negative pole continuously
- The electrons from sun light would be absorbed to positive pole and then the exceed electrons in positive pole move to negative pole.
- The exceed electrons in negative pole be released to the air and then it makes electrolysis of water. Hydrogen ion from electrolysis of water get electrons then become Hydrogen atom and then "OH-" ion would be released

- ANTI-BACTERIAL (Needs to add Anti-bacterial additive)

Sample kinds	Initial	After 24hrs	Antibacterial Efficiency(%)
① Blank	2.4×10^4	3.2×10^6	-
② Coated Board	2.4×10^4	10 >	99.9

Note :

- 1) Test condition : Film Attached Method (JIS Z 2801-2000)
 - a. The solutions and then inoculate the face of the sample. After the sample is cultivated at 30°C for 24hrs and dilutions of cultures are divided by pour agar plate method to determine bacteria cell growth inhibition rate
 - b. Sample area : 4 * 4 cm
- 2) Name of Used bacteria : *Escherichia coli* ATCC No. 25922

KOREA FAR INFRARED ASSOCIATION
KOREA INSTITUTE OF FAR INFRARED APPLIED ESTIMATION

CERTIFICATE OF TESTING RESULT

40, Songpa-Daero, Songpa-Gu, Seoul, Korea <http://www.kfir.or.kr> TEL: 82-2-2261-6925 FAX: 82-2-2261-6963

Serial No. of Issue : KIFA 108
Name of Applicant : Lee Sanghuk (TEBRAMICS INC)
Address of Applicant : 420-7, Cheongcheon-dong, Daejeon-gu, Incheon, Korea
Date of Receipt : 4. 18. 2014
Name of Test Sample : Ceramic

Test Item	Sample	TEST RESULTS		
		Early Con- (CFU/ml)	After 24 hours (CFU/ml)	Reduction Rate Of Bacteria(%)
Antibacterial Test For <i>Escherichia coli</i>	Blank	4.0 × 10 ⁶	5.1 × 10 ⁶	—
	Ceramic	< 1.0 × 10 ³	< 1.0 × 10 ³	99.9

Note) 1) The blank test was measured on non-test sample.
2) The bacteria number on the petri dish was detected by multiplication of dilution rate. End

1) Test method : KIFA-FI 003
2) Name of used bacteria : *Escherichia coli* ATCC 25922
3) Refer to the Enclosed (1-1)
4) Usage : Quality control

* This certificate of testing result shall be used within the purpose of its defined usage.

4 18 2014
month day year
Signer *Choi T. S.*
The director of Korea Institute of Far Infrared Applied Estimation



Test Method of Non-stick Property

- Reference Test Method

. CMA (Cookware Manufacturer Association) Standard

. Cookware Non-Stick Performance Food Tests (22.2.1 Egg test / 81page)

Scope : This test is applicable for cookware non-stick coatings only. The pass/fail criteria will only be valid for cookware non-stick formulae. This is a test for the cleanability of a product and not the release properties

Test Method :

Wash cookware in hot water at a temperature greater than 140°F containing liquid detergent. Heat the cookware on stovetop so that the surface of the base is between 300 and 350 °F. Cook a room temperature egg broken into the cookware without additional fat or other lubricant until firmly set and then remove the egg with a plastic or nylon spatula. Record whether the test food was removed intact and if the surface wiped clean. The surface is deemed to be wiped clean if unaided visual examination after wiping reveals no trace of solid material. A “pass” is recorded if there is no trace of solid material after wiping. “Fail” means traces of solid material remain.



7

Test Method of Non-stick Property

- NEOFLAM Test Method

High Temperature Heating

- Test condition :
 - ① Heating at $340\pm 10^{\circ}\text{C}$ (maximum 350°C), for 30minutes / Egg Frying at $195\pm 10^{\circ}\text{C}$
 - ② 1Cycle \Rightarrow Heating + Egg Frying (10x) + Wash
- Test method :
 - ① Initial Test: 10times of Egg frying before High Temperature heating
 - ② Repetition Test: 10times of Egg frying after High temperature heating \Rightarrow 10 cycles at most

Dishwasher

- Test condition :
 - ① Standard operating mode of dishwasher (65°C , 90mins), Egg Frying at $195\pm 10^{\circ}\text{C}$
 - ② 1Cycle \Rightarrow Standard operating mode of dishwasher(10 times) + Egg Frying (10 times)
- Test method :
 - ① Initial Test: 10times of Egg frying before dishwasher
 - ② Repetition Test: 10times of Egg frying after dishwasher(10times) \Rightarrow 10 cycles at most



Measuring temperature
Before non-stick test
($195^{\circ}\text{C}\pm 10^{\circ}\text{C}$)



Evaluating the grade
based on Eggs stuck to
the surface




8


Technological Limitation of Ceramic Coating in Non-stick Property



INTRODUCTION OF CERAMIC COATING



A liquid drop on solid surface



. As a scale of non-stick performance on the coating surface the contact angle of water drop has been used. Methyl chains on the ceramic coating surface shows higher contact angle than "C-F" chains on the PTFE coating and that is the reason why ceramic coating shows much better non-stick performance at the beginning.

. Ceramic coating which is made from natural mineral, oxide material, can't have non-stick property, so it must rely on organic non-stick material. There must be a limit amount to apply organic part in ceramic coating so the consistency of non-stick performance would be poorer than PTFE coating.



Beginning



After many time use




Technological Limitation of Ceramic Coating in Non-stick Property



INTRODUCTION OF CERAMIC COATING

Since Ceramic Coating has the same molecular structure with natural oxide mineral, it can't have any non-stick property



Component of Ceramic Coating

- ✓ Since the main molecule of ceramic coating is silica, it is impossible to get a nonstick property itself.
- ✓ Sol-Gel process can make oxide material from molecular scale so that it has various potential to make hybrid material
- ✓ Organic non-stick material in top coating solution which can make chemical reaction bond with ceramic coating structure gives non-stick property in ceramic coating.
- ✓ Because low specific gravity non-stick material may float on the coating surface and the possibility of chemical bond between ceramic coating and non-stick material is very low, ceramic coating's non-stick property has time limitation.



Non-Stick Property Improvement of Neoflam Ceramic coating





INTRODUCTION OF CERAMIC COATING

High Temperature Heating / Dishwasher nonstick Test

-COMPARISON ON TEST RESULT

Unit : cycle


Classification	1 st gen	2 nd gen	3 rd gen	4 th gen	5 th gen	6 th gen
High Temperature heating	0.5	1.0	1.3	2.3	4.6	8.4
Dish washer	0.3	1.4	1.3	2.4	4.5	9.0





10 Why Neoflam ?

◎ Research Network






10 Why Neoflam ?

© Government Support

. Gov. R&D Project with NEOFLAM (2016 ~ 2018)

Development of ceramic coated cookware with enhancing crack-free and nonstick function

[The main contents of the development & the configuration of the institutions]



Neoflam

- Multifunctional Ceramic coating process
- Crack-free & Micro-pore control Techniques
- Beautiful product development

Terramics

- Silan networks for Nonstick function
- Economic Sol-Gel Process for Ceramic coating
- Fine-tuning of complicate ceramic system


KITECH

- Controlling of Hydrophobic surface
- High thermostable hybrid ceramic material
- Material design for nonstick ceramic coating



10

Why Neoflam ?





10 Why Neoflam ?

◎ Manufacturing Process

. Cookware Manufacturing Process



- ✓ Die Casting : Make cookware shape with Aluminum ingot
- ✓ Fitting : Abrasion process of Die Casted product
- ✓ Sand Blast : Make roughness of cookware workpiece
- ✓ Coating Solution : Make Ceramic coating solution
- ✓ Spray Coating : Coat ceramic solution on cookware workpiece

⇒ You can handle and manage whole above process at one time and place with NEOFLAM



10

Why Neoflam ?

◎ Coating Process

Coating Process	What NEOFLAM is different?
Sand Blast	<ul style="list-style-type: none">. Surface roughness is very important variable to determine coating quality> Neoflam controls the surface roughness within 1 micrometer
Surface Cleaning	<ul style="list-style-type: none">. Dust and Impurity on the workpiece surface can make peel off of ceramic coating> Neoflam set 6step cleaning process [water -> alkaline degreasing -> water -> acidic treatment -> water -> distilled water]
Preheating	<ul style="list-style-type: none">. To get a good adhesion of ceramic coating preheating temperature is very important> Neoflam has specialized preheating oven to control . (15m , ~ 150°C)
Spray gun	<ul style="list-style-type: none">. Number and quality of spray gun is very important for coating quality> Neoflam uses much more guns than any other competitors (base: 18, top : 15)
Spray Booth	<ul style="list-style-type: none">. Dust in spray booth can attach on coating surface then it may cause coating peel off.> Neoflam runs dust free clean room which is able to manage temperature
Drying	<ul style="list-style-type: none">. Drying step is the most important variable to determine coating surface quality> Neoflam runs F-IR drying system to control evaporation speed
Curing	<ul style="list-style-type: none">. Curing temperature and time is key point to determine coating strength and quality> Only neoflam has the curing oven longer than 35 m













10

Why Neoflam ?

◎ Colors

. Basic Color and Main Components

	TiO ₂ , SiO ₂		TiO ₂ , Cr ₂ O ₃
	CdO , SiO ₂		CdO , SiO ₂
	CdO , Sb ₂ O ₃ , SiO ₂ ,		CuO , PbO, Cr ₂ O ₃
	CoO , CuO, MnO		TiO ₂ , Cr ₂ O ₃
	TiO ₂ , Sb ₂ O ₃ , SiO ₂ ,		Sb ₂ O ₃



- ✓ Ceramic coating needs to use high temperature resistant pigment to make color (up to 400°C)
- ✓ Most of Yellow, Red and Orange pigment contain heavy metal element (Cadmium).
- ✓ Most of Green and Black color pigment contain heavy metal element (Chromium)

⇒ *Only NEOFLAM can make any kind of color without heavy metal element.*



INTRODUCTION OF CERAMIC COATING

10 Why Neoflam ?

◎ Design

Main Award Career

1 World Class Product of Korea



세계일류상품

This award is for the company which occupy world market within 10th (Neoflam is 5th) and expert more than 5 million dollars from Korean government.

Neoflam was selected as a no.1 company in anti-bacterial cutting board and cookware market for 4 years continuously.

2. Design Award



reddot award 2016
best of the best



신개념 페달라이트 쿡웨어 '모투스'



특허 받은 분리형 쿡웨어 '마이팬'



reddot design award
winner 2013



네오플램의 첫 프리미엄 라인 '레트로'



reddot design award
winner 2013



건강함을 입은 칼/칼블럭 '아베코 칼 & 칼블럭'



reddot design award
winner 2013



차원이 다른 도자기 내열냄비 '밸리'



reddot design award
winner 2012



로맨틱 키친을 위한 혼수 필수품 '애니'



reddot design award
winner 2012



현대적인 도자기 내열냄비 '댄디'



product
design award
2012



홈쇼핑 판매 No.1 '일라'




Bringing kitchens to life



10 Why Neoflam ?

◎ History and Know-how



Bringing kitchens to life

THANK YOU FOR YOUR ATTENTION



Bringing kitchens to life